

Environmental Protection Agency

§ 761.280

of a minimum of 50 cm³ from the mixed composite for analysis.

(c) Use the following procedures to sample bulk PCB remediation waste that is in more than one container.

(1) Segregate the containers by type (for example, a 55-gallon drum and a roll-off container are types of containers).

(2) For fewer than three containers of the same type, sample all containers.

(3) For more than three containers of the same type, list the containers and assign each container an unique sequential number. Use a random number generator or table to select a minimum of 10 percent of the containers from the list, or select three containers, whichever is the larger.

(4) Sample the selected container(s) according to paragraph (b) of this section.

§ 761.267 Sampling non-porous surfaces.

(a) Sample large, nearly flat, non-porous surfaces by dividing the surface into roughly square portions approximately 2 meters on each side. Follow the procedures in § 761.302(a).

(b) It is not necessary to sample small or irregularly shaped surfaces.

§ 761.269 Sampling liquid PCB remediation waste.

(a) If the liquid is single phase, collect and analyze one sample. There are no required procedures for collecting a sample.

(b) If the liquid is multi-phasic, separate the phases, and collect and analyze a sample from each liquid phase. There are no required procedures for collecting a sample from each single phase liquid.

(c) If the liquid has a non-liquid phase which is >0.5 percent by total weight of the waste, separate the non-liquid phase from the liquid phase and sample it separately as a non-liquid in accordance with § 761.265.

§ 761.272 Chemical extraction and analysis of samples.

Use either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part, for chemical ex-

traction of PCBs from individual and composite samples of PCB remediation waste. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

§ 761.274 Reporting PCB concentrations in samples.

(a) Report all sample concentrations for non-liquid PCBs on a dry weight basis as micrograms of PCBs per gram of sample (ppm by weight). Report surface sampling results as µg/100 cm². Divide 100 cm² by the surface area and multiply this quotient by the total number of micrograms of PCBs on the surface to obtain the equivalent measurement of micrograms per 100 cm².

(b) Report all sample concentrations for liquid PCBs on a wet weight basis as micrograms of PCBs per gram of sample (ppm by weight).

Subpart O—Sampling To Verify Completion of Self-Implementing Cleanup and On-Site Disposal of Bulk PCB Remediation Waste and Porous Surfaces in Accordance With § 761.61(a)(6)

SOURCE: 63 FR 35465, June 29, 1998, unless otherwise noted.

§ 761.280 Application and scope.

Follow the procedures in this subpart when sampling to verify completion of the cleanup for self-implementing, on-site disposal of bulk PCB remediation waste and porous surfaces consistent with the levels of § 761.61(a)(4)(i) and (iii). The objective of this subpart is not to search for new contamination. Confirmation of compliance with the cleanup levels in § 761.61(a)(4) is only verifiable for the area sampled in accordance with this subpart. Do not make conclusions or extrapolations about PCB concentrations outside of the area which has been cleaned up and verified based on the results of this verification sampling.